


- CONTROL PROCEDURE**
PHASE 3
- 1) INSTALL SILT FENCES AT PROPERTY LINES.
 - 2) BRING STREETS TO GRADE.
 - 3) INSTALL TEMPORARY HAYBALES AND STAKE BERM IN STREET CHANNELS.
 - 4) INSTALL STORM DRAINS, SANITARY SEWER, AND REMAINING IMPROVEMENTS.
 - 5) FINE GRADE, SEED AND MULCH DIVIDED AREAS.

SEEDING SCHEDULE

UMC — 135 LB/1000 SQ FT
 FERTILIZER — 10-10-10, 20 LB/1000 SQ FT
 SEED — TALL FESCUE 40 LB/AC
 MULCH — SMALL GREEN STRAW



REV.	DATE	DESCRIPTION

BASS, NIXON & KENNEDY, INC.
 CONSULTING ENGINEERS
 7416 CHAPEL HILL ROAD
 RALEIGH, NORTH CAROLINA 27606

SURV'D BY: [Signature]
 OWN. BY: GAG
 CDD. BY: DKE
 DATE: 1-78
EROSION & SEDIMENT CONTROL PLAN
IRON GATE SUBD.
 SECT. II, PHASE THREE
 CARY, WAKE CO., N.C.

SHEET
2
 OF
 7